

## INSTRUCTION FOR LIGHT SOURCE/CONTROL GEAR

Applied to product family and references:

<b>BELGIUM</b>	<b>2.5201.1312   2.5203.1312   2.5204.1312</b>
<b>CANNES</b>	<b>2.5215.1312   2.5216.1312</b>

*Replacement instruction intended for a professional.*

*In case of doubt contact us.*


**Attention:** Before doing any works, switch off power of the mains supply or respectively of the connection lead and follow our safety precautions given in the product installation manual included in the product packaging.

- Read with care the installation manual according to product family included in the containing product.
- Uninstall the product in the reverse established order in the installation manual.
- Make sure that the product is place on a stable, even and safe environment.
- Separate the visor from the product by pulling it outwards.
- Hand unscrew the front cover until reach the light source like shown in pictures. Could be necessary to remove the spring which place the lens.
- The light source is assembled by screws, unscrew them to take it out.
- Collect all the removed parts of the replacement for a following reassembly.



*Pictures (as an example, the current situation may differ)*

- Once reached the light source, desolder the positive and negative cables from circuit.
- In case a control gear replacement is needed, unscrew the base of the LED module. Could be necessary to unscrew the base of the Led module with the help of pliers (see picture 3). Disconnect the control gear connection cables from terminal block and take it out unscrewing it or pry it from supporting element with a flat tool. The positive and negative cables could be removed (as applicable) either desoldering from LED module, unscrewing them from control gear or cutting them (leave enough space to solder them again when reassembly).
- By cooling reasons, a heat sink compound is needed between LED module and metal base. Please, be sure that the heat sink compound cover completely the LED module surface.
- In order to assemble again the product, proceed in the reverse order of this replacement instruction.



## INSTRUCCIÓN PARA FUENTE LUMINOSA/MECANISMO DE CONTROL

Aplica a la familia de producto y referencias:

<b>BELGIUM</b>	<b>2.5201.1312   2.5203.1312   2.5204.1312</b>
<b>CANNES</b>	<b>2.5215.1312   2.5216.1312</b>

*Instrucción de reemplazo destinada a un profesional.*

*En caso de duda, contacten con nosotros.*

**Atención:** Desconecte la línea de alimentación antes de realizar cualquier trabajo y siga las precauciones establecidas en el manual de instalación incluida en el embalaje del producto.

- Lea con atención el manual de instalación acorde a la familia de producto incluida en el producto continente.
- Desinstale el producto en el orden inverso al establecido en el manual de instalación.
- Preste atención que el producto esté en una base plana, estable y en un entorno seguro.
- Separar la visera del producto tirando de ella hacia afuera.
- Desenroscar manualmente la tapa frontal hasta llegar a la fuente luminosa tal y como aparece en las imágenes. Podría ser necesario retirar el muelle que coloca la lente.
- La fuente luminosa está montada con tornillos, desatornillelos para retirarla.
- Recopile todas las partes retiradas por el reemplazo para un posterior reensamblaje.



*Imágenes (como ejemplo, la situación actual puede diferir)*

- Una vez alcanzada la fuente luminosa, desoldar el cable positivo y negativo del circuito.
- En caso de ser necesario un reemplazo del mecanismo de control, desatornillar la base del módulo LED. Podría ser necesario desenroscar la base del módulo Led con la ayuda de unos alicates (ver imagen 3). Desconecte los cables de conexión de la regleta de conexiones del mecanismo de control y retírelo desatornillándolo o haciendo palanca desde el soporte con una herramienta plana. Los cables positivo y negativo pueden ser retirados (según aplique), desoldándolos del módulo LED, desatornillándolos desde el mecanismo de control, o cortándolos (dejar espacio suficiente para poder volver a soldarlos en el reensamblaje).
- Para una correcta disipación térmica, es necesario un compuesto disipador de calor entre el módulo LED y la base. Por favor, asegúrese que el componente disipador cubra toda la superficie del módulo LED.
- Realice el ensamblaje de nuevo de todos los componentes, en el orden inverso establecido en esta instrucción.